

MINI POD UNIT

MINI POD UNIT

This work platform provides a fast, simple and cost effective solution for low level access. The modern alternative to step ladders.

Ideal for one man use, unfold the unit, position the platform allowing the correct guardrail height and start work. Easily portable and manoeuvrable, either open or closed, the unit passes easily through standard doorways.

- Lightweight and robust
- Provides a working platform
- 0.75m wide x 1.45m length
- Optional platform levels 1mtr & 1.3mtr
- Fitted with lockable castors
- Non slip platform boards
- Easily transportable
- Can be transported in a small van or standard elevator
- Safety gate self latching for added security while working



Low Level Training Available



MINI POD UNIT

The ASCEND MINI POD TOWER is a unique design of towers, which allows us to access with the complete safety. Anti-Slip steps and platform with the safer access methods to assemble and dismantle. The number of components in the Tower-Kit is sufficient for proper installation.

WORKING HEIGHT	TOWER HEIGHT	PLATFORM HEIGHT	COMPONENTS	WHEEL	PODIUM FRAME FOLDABLE	PODIUM STANDARD PLATFORM	PODIUM STEPS	STABILIZER	PODIUM DIAGONAL 107CM LONG	TOTAL WEIGHT (IN KGS)	UNIT WEIGHT	
											3 MTR	2 MTR
				4.09 KG	18.50 KG	4.70 KG	3.30 KG	3.100 KG	1.200 KG	45.70	3.2 MTR	2.2 MTR
				4	1	1	2					1.2 MTR
				4	1	1	2	2	1			
								2				
									1			
										54.06		

ASCEND ACCESS SYSTEMS SCAFFOLDING L.L.C.

Tel : +971 4 885 5001

Toll Free : 800 722 33653

Email : sales@ascenduae.com

Website : www.ascenduae.com

MINI POD SCAFFOLD

The law requires that the personnel erecting, dismantling or altering the tower must be competent. Any person erecting Ascend Mobile Tower must have a copy of this guide.



Step 1
Unfold the podium foldable frame on a firm and level ground and lock the folding gate mechanism



Step 2
Lock all castor wheels



Step 3
Position platform on the 3rd rung



Step 4
Platform steps on 1st and 2nd rung and engage the windlock
AS ILLUSTRATION 3



Locked



Unlocked



The Complete Structure

MAINTENANCE RULES

Ensure that the PODIUM is kept clean.

Grease all moving parts with commercial oil. Wipe off excess oil.

Check frames and braces and boards for paint, grit, burrs etc. Remove any foreign substance with a light wire. If paint gets on the podium, it can be removed with turpentine.

Where brace and platform hooks attach the frames, ensure that the frame rungs are kept clean.

Ensure that all locking hooks function correctly. If necessary lubricate with light oil.


The inside diameter of all hooks should be kept clean to ensure they fit to other components without being forced.

If in any doubt about the proper use and maintenance of the podium, consult the manufacturer.

Do not misuse or abuse the podium with heavy objects, hammers etc. Do not throw components in and out of vehicles or to the ground when the podium is being dismantled. Such abuse may reduce the structural integrity of the podium. Under no circumstances damage or incorrect components shall be used, Either repair it or get replacement.

ILLUSTRATION


Assembly Process




1) Brace lock - Sort the braces into horizontal and diagonal braces, the diagonal braces are slightly longer in



3) Windlock - A windlock clip is installed on the platform at the hook. This is locked as shown here.



2) Snap pins - Unlock the interlock Clips on all frames. When installed, always move the interlock clip to the "Locked" Position.



4) Wheel lock - Install castor / leg assembly to frame by pushing the leg into the frame tube. This Should be done with manual force only, no tools. Lock Castors before ascending any part of the

GENERAL SAFETY RULES

1. Ensure all components are present and not damaged before use.
2. Do not use on unstable ground such as loose bricks, boxes or blocks.
3. Remove all personnel and materials before moving the folding unit.
4. When moving the unit, apply force manually by pushing at the base.
5. Do not gain height by using boxes, ladders, on the platform.
6. Ensure all castors wheels are locked.
7. Do not overload the unit.
8. Do not overreach out of the unit.
9. Erect *Podium* on a firm level ground
10. Beware of horizontal forces (e.g. when using power tools) which could generate instability or overturning of the tower. Maximum horizontal force 20Kg.

**MAX SAFE
WORKING LOAD
PLATFORM 150 KG**

For more information on this product please contact us on:

Toll Free: 800 SCAFFOLD (800-72233653)
Email sales@ascenduae.com